



## Sprso Giro Troubleshooting

### How to switch the machine to stand-by / How to set the stand-by timing

The espresso machine heats up water for the desired drink after you selected a drink, and pressed start. This saves energy when compared to machine with an internal hot water boiler, that requires that water in kept constantly hot.

You can further reduce energy consumption by switching the machine to stand-by after usage, or setting a time after which the machine automatically switches to stand-by.

#### 1. Setting the stand-by timer.



You can set the stand-by time in the programming menu. Press the **menu** key located above the display for 3 seconds.



Select **machine** with the left/right arrow keys. Press start, and select **automatic switch off**. Press start and set the timing with the left/right arrow keys. (30 min, 1, 2, 4 hours, no switch off) Press start to confirm.

Press the **menu** key to close the menu.



Empty the drip tray daily (as part of regular daily maintenance).

The machine dispenses a small amount of water to rinse the outlet when it is switched on or off.

#### 2. Switching the machine directly to stand-by.



Press the start button for 5 seconds to switch the machine to stand-by.

The machine dispenses a small amount of water to rinse the outlet and switched to stand-by (the start-key starts blinking).